

BOUNCE HOUSE RULES



CHILDREN MUST BE SUPERVISED AT ALL TIMES.

SPECIFIC RULES TO FOLLOW:

1. Participants in the bounce house at the same time, must be of the same age group. However, an adult may accompany a small child if necessary. See rule 3 for more information.
2. The Bounce House is designed for children. Bouncers should not sit or lay down while others are bouncing around them, as a jumping child could fall down on top of a sitting or lying child.
3. The maximum number of people allowed in the standard 10 X 10 Bounce House is:
 - Ages 2 to 53 children maximum + 1 Adult
 - Ages 2 to 86 children maximum

Please note:

- Max Gross Weight: 600 Lbs.
 - Max Players: 6
 - Max User Weight: 200 Lbs.
4. All persons must remove shoes, glasses, jewelry, and anything else that may harm the Bounce House or other users of the Bounce House or anyone in doors around the Bounce House. All bouncers must empty their pockets before entering the Bounce House.
 5. No flips, somersaults or horseplay. Do not run and/or bounce against the walls. Do not run or jump through the door of the Bounce House. Do not climb or hang from the interior or exterior of the Bounce House.
 6. No food or drink inside or near (within 10 feet) of the Bounce House. The cleaning deposit will be returned upon inspection of the sight and the bounce house itself. NO SILLY STRING. Silly string damages the vinyl. You will be charged for all repairs required from silly string damage.
 7. Please do not tape or fasten anything to the Bounce House.

SHOULD THE BOUNCE HOUSE BEGIN TO DEFLATE:

1. If the motor has stopped - check the cord connection at the outlet and at the motor. Remember use of more than one extension cord can trip the circuit breaker.
2. If the Bounce House starts to deflate - check the air intake on the side of the motor for blockage. Check both tubes on the back of the Bounce House for snugness and retie if necessary.
3. If the Bounce House stakes come loose, pull the corner back and re-stake.
4. Should the Bounce House deflate, or if you experience any other problems with the equipment, please call Parks and Recreation at the following phone number 874-2444 before allowing or engaging in further use of the bounce house.